

Operating Instructions

HEROSHI SAISHO JUICER



Before operating this unit, please read these instructions completely

TANOSHI KENKO ENJOY GOOD HEALTH

SPECIFICATIONS

Voltage:	220-240V~50-60Hz
Power:	130W
Juicing cup capacity:	600ml
Pulp container capacity:	450ml
Juicer size:	98mm x 120mm x 355mm
Weight:	1.58kg


1. The Heroshi Juicer is designed for household use only.
2. Commercial users will not obtain the regular warranty as stated in the terms of the warranty card.
3. This is not a toy. Please do not let children play with it or use it.
4. Read all instructions before use carefully.
5. Keep these instructions for ever.

IMPORTANT SAFEGUARDS

1. Make sure the electricity supply is 220-240V.
2. This juicer is intended for household use only. Do not use the juicer outdoors or for other purposes.
3. Use the Heroshi juicer only as described in this manual.
4. To prevent electrical shock, do not immerse the juicer, cord set and plug into water. Operate the juicer at a safe distance from water.
5. This is not a toy and not to be used by children. Close supervision is required when the juicer is used near children.
6. Ensure to unplug the juicer when not in use, when assembling or disassembling, and before cleaning.
7. The continuous operation time limit for this juicer should be within 20 minutes.
8. Do not touch or move any moving parts during operation of the juicer.
9. Do not use finger, spoon or chopsticks to push fruits or vegetables in to the chute of the juicer. Only use the pusher provided.
10. Do not open the juicer when it is operating.
11. Do not place the juicer near any heated oven or hot surfaces.
12. Operate the Heroshi juicer on a flat surface.
13. Do not let the cord hang over the edge of the table or the bench top.
14. Please hold the plug to disconnect from the power socket.
15. If the parts of the juicer are found to be damaged (especially the power cord) please stop using it.
16. This product is not intended to be operated by persons (including children) with weak physical condition, slow reaction, mental retardation, lack of experience and common sense, unless they are under supervision or instruction by the person who is responsible for their safety.
17. If the screw press gets obstructed, put the juicer in 'rev' mode for about 2 to 3 seconds to let it turn in the opposite direction and loosen the blockage. After this, revert to using the product as usual.
18. Don't use the water that is warmer than 65°C to rinse the appliance parts
19. Make sure that the base of the juicer does not get wet.

HINT: This Juicer is not suitable for juicing very hard or fibrous and starchy fruits or vegetables such as Sugar Cane. There are some fruits which contain too much starch to juice. They include avocado, bananas, figs, mango and papaya, dragon fruit, strawberry, and grapes without seeds. They will clog up the stainless-steel sieve.

PARTS DIAGRAM



- | | |
|-------------------------------|------------------------------|
| 1 Food Tray | 8 Pusher |
| 2 Chute and Strainer Assembly | 9 Cleaning Brush |
| 3 Squeezing Auger | 10 On / Off / Reverse Switch |
| 4 Juicing Bowl | 11 Juice Spout |
| 5 Power Base | 12 Drip-stop cover |
| 6 Juice Container | 13 Pulp Spout |
| 7 Pulp Container | 14 Power Cord |

NOTE

To avoid hazard of electric shock, unplug the juicer from power outlet when not in use or before cleaning. If the power cord is damaged, stop using immediately and have it repaired by an appropriately qualified technician.

FIRST TIME USE

1. Remove all packaging materials, plastic bags and labels.
2. Make sure the electricity supply is 220-240V~ 50-60Hz.
3. Clean the Food Tray / Chute and Strainer Assembly / Squeezing Auger / Juicing Bowl / Pusher with Soapy water. Then rinse and dry thoroughly.

NOTE: DO NOT IMMERSE THE POWER BASE JUICER IN WATER.

4. Assemble the parts per the instruction in the assembling method section.
5. Connect the power cord to the power source. The Heroshi juicer is ready to use now.

ASSEMBLY

Make sure the juicer is not plugged in and the switch is turned to 'O' setting before assembling.

1. Position the squeezing bowl on the Power base, align the position of the spouts and the axle. (Fig 1)
2. Push the squeezing auger firmly into the center of the bowl, making sure that it touches down the bottom, or else the cover cannot be closed. (Fig 2)
3. Position the chute on the bowl to align the ▲ to the 🔒 and twist it clockwise until it clicks the safety lock. Please make sure that the arrow ▲ on 🔒 the cover aligns with the Lock graphic on the Bowl. (Fig 3)
4. Place the juice container and the pulp container under the relevant spouts. (Fig 4 below)




Fig.1



Fig.2




Fig.3




Fig.4

OPERATING GUIDE



1. Connect the juicer with power.
2. Check and make sure all parts are well assembled and firmly in their correct position.
3. Make sure the juicer is at off 'O' position.
4. Make sure the juice and pulp containers are in position.
5. Make sure the juice spout cover is closed.
6. Prepare fruits or vegetables and cut them into pieces max 2cm x 5cm strips or 2cm x 2cm cubes.
7. Feed fruit into the chute.
8. Press the switch to Setting ' - ' to start the juicing operation.
9. Push the food down with the pusher only.
10. In case of food stuck inside the Bowl, please switch to "R" reverse function instantly.

NOTE

Please do not use the juicer continuously for longer than 20 minutes.

Open and Close of Juice Spout Cover

During the juicing process, you could keep the Drip-stop Cover closed before the juice is full in the juicing bowl. (Fig 5 below)



Benefits of drip-stop cover

1. To stop dripping at the end of juicing.
2. Mix juice with different fruits and veggies.

Usage Tips

1. Remove hard pits or seeds prior to pressing to prevent damage to the squeezing screw.
2. If making mixed juices, please begin with harder fruit, and then squeeze the soft fruit.
3. Let the juicer run for 30 seconds after the last ingredient was fed.

Attention

The juicer is not suitable for juicing very hard or fibrous and starchy fruits or vegetables such as sugar cane. There are some fruits which contain too much starch to juice. Some examples are avocado, bananas, figs, mango, papaya, dragon fruit, strawberry, grapes without seeds etc. They will clog up the stainless-steel sieve.

DISASSEMBLY METHOD

NOTE

If the juicer gets overheated, it will turn off automatically to protect the juicer. In this case, please turn the juicer off 'O' then wait 10 minutes to let the juicer cool down and then turn it on again.

To disassemble the juicer after using and before cleaning. Please turn the juicer to 'O' position and disconnect the juicer from power source then follow the steps below:

1. Remove the Juice and Pulp containers. (Fig 6)
2. Remove the Chute. Turn the chute anti-clockwise until the ▲ aligns with the 🔒 sign. (Fig 7)
3. Remove the Squeezing Auger by pulling it out upward. If it is very hard, swing gently and pull. (Fig 8)
4. Remove the Squeezing Bowl by lifting it upward vertically. (Fig 9)




Fig.6




Fig.7



Fig.8





Fig.9

CLEANING AND MAINTENANCE

IMPORTANT


Please wash the juicing parts every time immediately after each used, otherwise the pulp might stick tightly in the Juicing Bowl and on the Squeezing Auger which will then affect the disassembly, cleaning and juicing performance.

1. Switch off and unplug the juicer.
2. Wash the disassembled parts (**Fig 10 below**) with water. If the meshes are clogged with pulp, please use the cleaning brush provided to remove the dregs.



Attention:

- Do not use an iron wire brush, abrasive or sharp tool to clean the juicer.
 - Please do not use water above 40°C.
 - Never clean any parts in dishwasher to avoid damage by hot water.
3. In case there is any residue remaining in the mouth of the pulp spout, please pull out the silicone valve as shown in (**Fig 11 below**) and clean under running water.



Press the silicone valve to close it properly and tightly after cleaning.

4. To Clean the seal ring in the center of the squeezing bowl, please follow the steps as below:
 - a. Turn the Squeezing Bowl upside down for easier handling, Push the seal ring out with your thumb (Fig 12a) and clean it with water.
 - b. After Cleaning, please put it back to the center hole. The small ribbed surface should be facing upward (Fig.12b) Make sure the groove of the seal ring fits well in the squeezing bowl.
 - c. The big flat side of the seal ring will be inside while the small and ribbed side is outside the Squeezing Bowl. (Fig 12c)



Fig 12a



Fig 12b



Fig 12c

5. Do not put the Power Base into water for cleaning. Wipe it with damp cloth only.
6. After cleaning, please dry the parts thoroughly and store them in a dry, cool place.

STORAGE

1. Follow cleaning instructions to well maintain the juicer before storage.
2. Tidy up the power cord set.
3. Store the juicer away from easy access by children.
4. Store the juicer and the accessories at a dry, cool place.

NOTE

Please make sure the juicer and parts are dry before storage.

USEFUL TIPS

Item	Warning	Reason
1	Not for Ice cube.	The ice cube is too hard. It may damage the squeezing parts.
2	Ingredients with long fiber need to be cut to 2-5cm thin strips or 2 x 2cm cubes.	Long fiber food may block the spout.
3	The peel, pips and seeds must be removed from oranges, lemons, grapefruit and melons before use.	The hard pit or seeds may damage the squeezing parts. The peel may block the spout of pulp.
4	Do not use other implements as a pusher.	It may damage the juicer and cause injury.
5	Each juicing cycle no longer than 20 mins.	Using the juicer beyond 20 minutes may cause damage to the motor.
6	Never put spoons or chopsticks in the Chute opening, the juice and pulp spouts.	It may damage the juicer.

TROUBLE SHOOTING

Trouble	Cause	Solutions
The juicer stops running suddenly.	Too many ingredients put into the juicer	Switch to 'R' position instantly to make the ingredients return upwards. If the juicer still stops running, please clean the juicer before re-use.
	Hard fruits or vegetables have not been cut in small pieces.	Hard fruits and vegetables (such as carrot) should be cut into thin strips or small cubes before putting into chute.
The juice yield is low or juice flows out of the main housing.	The Bowl and the silicone valve are not installed properly.	Please re-install the Bowl and silicone valve by referring to the installation method.
Abnormal noise.	Parts cause extrusion sound during squeezing.	The sound is caused by extrusion of fruits and vegetables, which is normal phenomenon.

TROUBLE SHOOTING *continued...*

Trouble	Cause	Solutions
The Chute and Strainer Assembly cannot be opened.	There is too much pulp inside the bowl.	Press switch to 'R' setting to eject the pulp backward.
	Hard foods stuck inside.	Press switch to 'R' to eject the object backward.
	The pulp mess is stuck.	Pour water into the Chute to soften the stuck pulp mess overnight.
The container and accessories are dyed after use.	Dyed parts are due to natural colour of specific fruits/veggies.	This is natural color and unavoidable.

5-YEAR WARRANTY

Heroshi certifies that the Heroshi Juicer is free from defects in material and workmanship from the date of purchase. This warranty does not cover damage caused by misuse or abuse, accident, the attachment of any unauthorized accessory, alteration to the product, or any other conditions beyond the control of Heroshi. The Heroshi Juicer is made for household use.

Heroshi shall not be responsible for any type of incidental, consequential, or special damages. This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual state regulations, some of the above limitations and exclusions may not apply to you.



The Iron Rejuvenator

Ideal juice when you need a quick pick me up.

Ingredients: 1 large beetroot, 2 carrots, 1 large apple, 50g baby spinach and ½ lime.



Mean Green Juice

A hardy juice to boost the immune system.

Ingredients: 1 large cucumber, 2 apples, 2 kale leaves, 2 stalks of celery, ½ lemon and 1cm ginger.



Carrot and Capsicum Surprise

An amazing juice to make you feel more energized.

Ingredients: 4 carrots, 1 red capsicum, 1 pear and 1 lemon.



Detox Juice

Kick starts a sluggish system with this great tasting juice.

Ingredients: 1 small bunch mint, 1 large apple, 2 kale leaves, 50g pineapple (peeled), ½ cup baby spinach, ½ lime and 2 stalks of celery.



Beet me to it

A high energy juice to stimulate the mind.

Ingredients: 1 beetroot, 1 apple, 2 carrots and ½ cucumber.



A Wonderful Delight

A wonderful juice that will refresh and revitalize the mind and body after a late night.

Ingredients: 2 grapefruit, 1 cup watermelon, 1 carrot and ½ lime.



Ginger and Coriander Bliss

A cleansing and refreshing juice to tickle your taste buds.

Ingredients: 1 lemon, 1 cup coriander, ½ cucumber, 1cm ginger and 4 stalks of celery.



Just Breathe

With cool tones of mint this is a fresh juice you will not want to end

Ingredients: 2 oranges, 2 carrots, 1 large handful mint, 1 tsp ginger, 1 pear and ½ lime.



Summery Herbs

A juice packed of summery herbs and flavors, perfect for a sunny day.

Ingredients: 10 mint leaves, 1 cucumber, ½ cup basil, ½ cup parsley, 2 apples, ½ lemon and ½ lime.



Tropical Refreshen

Great for a summers day, serve over ice as a Mocktail.

Ingredients: 1 cup watermelon, ½ cup pineapple, ½ cup mint, 1 lime.



Be Still Lemonade

All the refreshment you get from a fizzy lemonade but with a much healthier approach.

Ingredients: 2 cups spinach, 1 apple, 1 pear, 1 cucumber, ½ lemon and ½ lime.



Regain

Allow this juice to calm down your entire body and regain your energy.

Ingredients: 1 apple, 2 kale leaves, 1 cucumber, ½ cup broccoli (chopped), 1cm ginger and ½ lime.

HEROSHI

PLEASE DO NOT HESITATE TO CONTACT

Heroshi

4 Pirelli Street Southport QLD 4215

Freecall: 1800 616 248 • Email: info@heroshi.com.au

Country of Origin: China



Please dispose of
packaging thoughtfully
and recycle where possible